

Safety Inspection

A dam safety inspection program is important to successfully operate and maintain your dam. This program typically consists of two types of inspection, a periodic engineering inspection and an operational inspection. Engineering inspections are required every 3 or 5 years, depending upon the hazard classification of the dam.

Regular operational inspections are typically conducted by the owner or the operator of a dam. These inspections should involve visual inspection of the dam, along with the recording of data obtained from staff gauges or other instrumentation on-site. An average inspection takes about 2-3 hours.

The Inspection

It is helpful to prepare an inspection route in advance to assure that every part of the dam will be observed. The following is a recommended sequence to assist in your inspection:

CREST - Walk across the crest from end to end.

UPSTREAM AND DOWNSTREAM SLOPE - Walk across both slopes in an up and down or zigzag pattern from end to end.

EMBANKMENT-ABUTMENT CONTACTS - Walk the entire length of the embankment abutment contacts (groin).

OUTLET CONDUIT - Observe all accessible features of the outlet conduit.

SPILLWAY - Walk along the entire length of the spillway in a back and forth manner.

DOWNSTREAM CHANNEL - Travel the route of the stream below the dam to maintain familiarity with locations of residences and property which can be affected by dam failure.

DOWNSTREAM TOE - Walk the entire length of the downstream toe.

Safety Inspection

Things to Look for During an Inspection

Principal Spillway

The principal spillway may be a concrete or rock weir or channel, or a concrete, plastic, or metal pipe. Concrete weirs and channels should be checked for cracking, settlement, deterioration and undermining. Pipes should be checked for corrosion, settlement, cracking, joint separation, leakage and undercutting

Auxiliary Spillway

The auxiliary spillway, also commonly referred to as an emergency spillway, is typically an overflow spillway designed to operate prior to overtopping the remainder of the earth embankment. The spillway should be checked for erosion and seepage, along with blockages caused by fences, logs, trees, brush, or other debris.

Inlet or Outlet Works

Inlet and outlet works may include gates, stoplog bays, valves, and other structures used to regulate water for a specific purpose. The operation of gates and valves should be checked, and gates and valves should be checked for rust, cracking, or misalignment. Stoplogs should be checked for deterioration and leakage.

Trash racks

Trash racks are typically found at the inlet of the principal spillway. The trash racks should be inspected frequently to make sure they are unobstructed, to provide for the free flow of water. Trash racks are also prone to rusting.

Earth Embankments

The majority of dams in Kansas consist of earth embankments. These earth embankments are susceptible to deterioration by both internal and external erosion, slides, cracking and damage by woody vegetation and animals. Owner inspection of earth embankments should include observation for seepage, cracks, settlement, slumps, erosion, scour, vegetative growth, and animal burrows.

Safety Inspection

Seepage

Seepage is the passage of water through or under the earth embankment, or the contact between the embankment and other structures. Nearly all dams will experience some seepage. In some cases, a drainage system has been installed at the downstream toe of the dam to collect seepage. Dam owners should monitor seepage for changes in the quantity of seepage, as well as for soil particles present in the seepage. If cloudy water is observed with the seepage, internal erosion or piping of the embankment may be occurring. Piping is a dangerous condition which could lead to failure of the dam. If piping is observed at your dam, you should immediately contact the Kansas Dam Safety Program or an engineer experienced in dam safety.

Cracking

Cracking of an earthen embankment is an indication of differential movement of the dam. Settlement of an earthen embankment indicates either the loss of material from the embankment, or additional compression of the embankment or foundation materials. Both conditions are indicators of embankment instability; and if either condition is observed, you should immediately contact the Dam Safety Program or an engineer experienced in dam safety.

Vegetation

Vegetative cover for dam embankments should consist of a suitable growth of grass. Bare embankment slopes are susceptible to erosion, and the presence of cattails and other water-loving vegetation is often indicative of a high water surface within the embankment. Tree and brush growth on embankments is also undesirable, as it provides cover for burrowing animals; prevents a thorough inspection of the embankment; provides an avenue for seepage as roots decay; and if trees tip over during windstorms, the loss of soil around the root mass can compromise the integrity of the embankment.

Scour

Scour is underwater erosion caused by the rapid flow and turbulence from a spillway or high velocity. Since this generally occurs underwater, observation of the condition is often difficult. In some cases, probing with a long rod can be used to detect and approximate the extent of scour.

Animal Burrows

Animal burrows result in a loss of earth material and can provide seepage paths. Animals should be removed and holes backfilled with soil.

Safety Inspection

Keeping Records

It is important for the dam owner/operator to keep records throughout the existence of the dam. Accurate records can better illustrate the dynamic nature of the structure. The following items will aid the dam owner or operator in keeping good records.

Inspection Checklist - A convenient way of compiling inspection observations is by recording them directly onto an inspection checklist. The checklist should be attached to a clipboard and carried by the dam inspector as they traverse the entire structure. A sample checklist has been included as an addendum to this fact sheet.

Field Sketch - A good practice to follow, along with filling out the inspection checklist, is to draw a field sketch of observed conditions. The field sketch is intended to supplement the information recorded on the inspection checklists, however, it should never be used as a substitute for clear and concise inspection checklists.

Photographs - Inspection photographs can be vitally important. Over time, photographs serve to provide a pictorial history of the evolving characteristics of a dam. The dam owner or operator often finds them to be great money savers because they can illustrate that some observed conditions (seepage, foundation movement, etc.) have existed for many years and may have reached a state of equilibrium.

With this knowledge, quick and economical remedial actions may be developed and implemented. Photographs should be dated on the back and provided with brief descriptions of the locations shown in the pictures.

Monitoring Data - As previously indicated, it may become necessary to make measurements of various items during the course of a dam inspection. This may include measurements of seepage rates, spillway discharge rates, settlement, and for some dam owners, readings from instruments such as piezometers. It is important that this data also be compiled in a systematic manner and placed in a permanent file.